

Agilent DSO-X 2002A quick reference guide

For on-screen help

Press the Help button (next to Channel 2 controls)

To get on-screen help about a particular control, press the control and hold it for at least 2 seconds. Note that all rotary controls also have a push button in the centre.

Before you start, clear all previous users' settings

Press Default Setup

To display a trace

Run/stop light should be green

Connect input signal to Channel 1

Channel 1 button should be lit up green. If not, press it to turn on Channel 1.

Press Auto scale

To capture a trace

1. Use Intuilink toolbar in MS Word

2. Use Intuilink data capture on the PC.

Start > All Programs > Agilent > Data Capture > Run IntuiLink Data Capture

3. Plug a USB flash drive into the DSO then:

File > Save/Recall > Save > Format > PNG 24 bit image (recommended rather than BMP)

Save to \usb then select a folder to save it to then Press to save

To use ASV to do an FFT

Start > All Programs > Agilent Spectrum View Infinivision